"not a product supplier but...
a technical partner!!"



INDUSTRIAL BATTERY SOLUTIONS

MICRO-POROUS POLYMER / SILICA SEPARATORS - WOVEN & NON-WOVEN GAUNTLETS



Amer-Sil: since 50 years focus on components for Industrial batteries

- ✓ 1970 Foundation in Kehlen, Luxembourg: JV Amerace & Tudor Sweden
- √ 1987 Acquisition of Amer-Sil by The Moore Company, textile focus Group
- √ 1989 Starting Production of non-woven gauntlets (1st player Worldwide)
- ✓ 2014 MBO, today AMER-SIL is fully independent with long-term plans and a stable organization, from that date...



✓ 2015 JV Amer-Sil / Ketex → today Amer-Sil Ketex by far the leader in India and Amer-Sil worldwide leader



AMER-SIL : worldwide presence

- ✓ Focus on Global Presence with Glo-cal attitude
- ✓ Globally 750 people
- √ 7x local Manufacturing sites:
 - ✓ 1x Luxembourg : HQ
 - √ 3x India (delivering domestic & European market)
 - √ 1x Bangladesh
 - √ 1x China (delivering domestic market)
 - √ 1x Brazil (dedicated to Latin America)

- ✓ ONE common know-how
- ✓ Sales in the 5 continents in every country there is an Industrial battery OEM





AMER-SIL SA, Head Quarter in Luxembourg

- √ 120 Employees
- ✓ Since 2014 R&D team from 3 to 15+ people in young/dynamic team with many ongoing research projects in partnership with :
 - ✓ LAVAL University in Montreal, Canada
 - ✓ Fraunhofer Institute, Germany
 - ✓ KU Leuven, Belgium
 - ✓ CNRS (National Center of Scientific Research), France
 - ✓ Projects with "Luxembourg National Research Fund" and "Marie Skłodowska-Curie" EU program







- ✓ New R&D & test labs
- The battery supplier strongly involved in battery research:
 - ✓ Electrochemistry lab
 - ✓ Battery testing lab
 - ✓ Member of ALABC



!! YOU tell us your needs → we define WITH YOU a customised/dedicated solution !!









Continuous improvement & LEAN approach

General & Operations current management coming from automotive background

In the last 10 years turnaround scenario with focus on:


- ✓ **LEAN** MANUFACTURING
- ✓ CONTINOUS IMPROVEMENT
- ✓ KEEPING OUTSTANDING CONSTANT QUALITY
- ✓ Focus on machines automatization to strongly reduce human mistakes and to be able to duplicate our quality into our several locations worldwide
 - → quality: machine-dependant and not people-dependant



Components for INDUSTRIAL lead acid batteries

Gauntlets for tubular plates: Woven & Non-Woven

Amer-Sil + Ketex benefit of 60 years of consolidated experience on this product, Today supplying 750+ Millions Lmt





Components for INDUSTRIAL lead acid batteries

Microporous PVC / Silica Separators

Amer-Sil benefits of 50 years of experience on this product





Main features of an endless-evolving solution

- ✓ Made of : PVC / Silica / Solvent / Carbon Black / Stabilizers
- ✓ Extruded and calendared with unique process
- ✓ No mineral oil and no resin added
- ✓ Thicknesses ranging from approx. 0,35mm to 5+mm (on demand)
- ✓ It can be laminated with Glass Mat in case of flat positive plates

Not to forget...

- ✓ Thermal stabilizer, no more Chlorine issues <u>since 2003</u>
- ✓ Our PVC composition much more flexible that in the past: available in leaf but also in <u>rolls and sleeves</u> (NEW)



AMER-SIL proposes since 50 years the pure PVC/Silica

- ✓ **Pore volume**: 73%, the **most porous** plastic separator in the market (and we can achieve more...)
- ✓ Acid displacement: among lowest value on market
- ✓ Electrical resistance: thanks to optimum pore distribution we facilitate ionic movement through a short path way
 → lowest ER value on market
- ✓ In 2019 our Backweb (today as thin as **0,35mm**) will be further reduced :
 - ✓ even lower ER!
 - ✓ even less acid displacement!
- ✓ Long life due to excellent *resistance to oxidation*
- ✓ Wettability: immediate wetting thank to exposed Silica particles (important parameter during battery acid filling process, especially in Gel)



Resistance to Oxidation: BCI Method

Procedure: Hydrogen peroxide

SEPARATOR

Oxidizing solution



Hydrogen Peroxide solution in sulfuric acid

3 hours in solution stabilized at 80°C

Wash in distilled water

Weight loss (%)

Copyright AMER-SIL SA




Oxidation resistance: BCI Method

Procedure: Hydrogen peroxide

BCI

Peroxide

Samples before oxidation test



Samples after oxidation test



Amer-Sil Flex-Sil Cell Sintered Darak **PVC** force



To summarize...what AMER-SIL can offer:

- ✓ <u>Technical partnership</u> with common development of products following your specific needs.
- ✓ **Reliable supplier** thanks to our persistent quality
- ✓ Customized solutions in terms of :
 - ✓ For Gauntlets: -material, -diameter (upto 1,2 inches), -size, -design (round, square, elliptical)
 - ✓ For Separators: -thickness, -size, -design

✓ <u>Very short delivery</u>

- ✓ We deliver the Separators from our plant in Bangalore where we increased every year our production capacity by 20%+
- ✓ Space available at every ASK location for installation of odd machines
- ✓ AMER-SIL is the only truly independent player in Industrial → the only long-term consistent partner !!



Thanks for your interest !!

